



INSTRUCTION MANUAL

12

KORETRAK PRO

This latest Koretrak has an upgraded sensor that covers most skin pigmentation including tattoos to give a more accurate heart rate and SpO2 readings. It can also detect your skin temperature and calculate your baseline temperature after a few readings.

IMPORTANT SAFETY INFORMATION

- To prevent personal injury or damage to your Koretrak Pro, read the following guidelines carefully to ensure proper usage:
 - Avoid exposing Koretrak Pro to chemicals, caustic liquids, and extreme heat.
 - When cleaning Koretrak Pro, do not use harsh solvents such as alcohol, benzene, acetone or thinner.
 - Do not attempt to disassemble Koretrak Pro or remove the battery.
 - If you feel any discomfort while wearing Koretrak Pro, loosen the wristband and discontinue using.
 - This is not a medical diagnostic device.
 - Do not use in a bloody environment such as sauna or hot spring. Not for swimming or diving.

Warning: This device is not a toy. Keep away from children.

13

READ ME FIRST

The Koretrak Pro is equipped with an integrated charging USB connector.

To charge your device, please remove the bottom watch strap. The USB connector is marked with "USB" markings on the back of the watch.

Plug into a 5V 1A USB-A port to charge (not included). If the charging does not occur, or by flipping the connector 180°.

For completely drained battery, it might need about 3-5 minutes to charge before the screen and touch sensor are responsive. This is normal.

TIPS FOR USE

For best performance, keep device screen clean and worn snugly on wrist.

14

CHARGING THE BATTERY

- The Koretrak Pro is equipped with an integrated charging USB connector. To charge your device, please remove the bottom watch strap. The USB connector is marked with "USB" markings on the back of the watch.
- Remove the bottom wristband to access the charging connector with a least and put motion (refer to diagram 1). You can find the connector side under the Koretrak Pro market "USB" with an arrow pointing at it. The USB metal contacts should be visible (refer to diagram 2).
- Plug the charging connector into your computer's USB port or a wall socket with a USB adapter. Make sure your power source is at least 2V. It might take up to 3-5 minutes for the watch to be charged.
- If Koretrak Pro does not charge after inserting the connector, it may be inserted in the wrong orientation. Unplug Koretrak Pro, flip it and insert the USB connector (refer to diagram 3). When properly connected, Koretrak Pro will vibrate and start charging.
- Allow Koretrak Pro to charge for up to 2 hours or until the battery indicator on the screen starts to full.
- Remove the device and disconnect the watch strap.
- Press firmly to ensure water resistance, there should be any visible gap between the case of the watch and the watch strap.

TIPS FOR USE

Note: You can locate the USB connector by looking at the back of your Koretrak Pro. There you will find markings of USB and an arrow pointing at it. If the Koretrak Pro does not charge, it may be inserted in the wrong orientation. Unplug Koretrak Pro, flip it and insert the USB connector (refer to diagram 1). If the Koretrak Pro does not charge, it may be inserted in the wrong orientation. Unplug Koretrak Pro, flip it and insert the USB connector (refer to diagram 1). If the Koretrak Pro does not charge, it may be inserted in the wrong orientation. Unplug Koretrak Pro, flip it and insert the USB connector (refer to diagram 1).

15



16

TIPS FOR USE

- Koretrak Pro requires 20 seconds to get a heart rate or blood oxygen reading.
 - For optimal performance, it is recommended to wear Koretrak Pro on your wrist for at least 10 minutes.
 - To keep Koretrak Pro clean, wipe it down with a damp cloth once a week or after physical activities.
 - To maintain consistent sensor reading, it is recommended to clean the sensor at the back of the watch after use. Dirt, lotion, grease or excessive water and sweat will affect sensor performance.
- FASTENING THE WRISTBAND:**
- The device sensor requires a close skin contact on your wrist to get an accurate reading.
 - Strap Koretrak Pro in place on the outside of your wrist.
 - Tighten the wrist band until you feel it has a firm grip around your wrist, but not so tight that it cuts off circulation, then fasten the buckle.
 - To remove the device, loosen an buckle.



Left Hand

17

INSTALLING THE KORETRAK PRO APP:

- Download the Koretrak Pro App onto your iOS or Android smartphone by scanning the QR codes below or by searching "DayBand" in the App Store or Google Play Store.
- Device requirements: iOS 8.0 and above; Android 4.4 and above.



CONNECTING KORETRAK PRO TO YOUR SMARTPHONE:

You will have to pair your Koretrak Pro to your smartphone manually the first time you use it. After that, it will connect automatically whenever your device is within range. Your Koretrak Pro can store off-line data for up to 7 days before syncing with your smartphone.

USING KORETRAK PRO:

- Hold the DAYBAND APP on your smartphone.
 - Open Koretrak Pro near your smartphone or go to Device page, click "Add a new device".
 - Choose corresponding Bluetooth name "Koretrak Pro".
 - Connection completed.
- USING KORETRAK PRO:**
- Koretrak Pro is equipped with a capacitive touch button located at the bottom of the screen.
- Short press to scroll through all the modes.
 - Long press to enter or exit mode.

TIPS FOR USE

Capacitive touch button should be affected by conductive media such as water from shower or rain. Make sure the touch interface is clean and dry when using.

18

TO TURN ON KORETRAK PRO:

- Long press function button to turn on the device.
- If the device cannot be turned on, it is possible that the battery might not be full, please charge it on a 5V rated USB power supply for up to 3-5 minutes. Please refer to the charging instruction on page 4-5.

HOME SCREEN

The home screen displays the date, weather, kinetic status and other essential information.

To change the home screen display style, long press to enter the device between the 3 different home screen designs.

MEASUREMENT MODES

- To cycle through measurement modes, short press the function button while the device is on home screen.
- Long press function button to enter function modes (i.e. Sports, messages and more).

PEDEOMETER

Records the number of steps you have taken.

ODOMETER

Records the distance you have traveled.

Weekly Reminder: The odometer measurement can be changed from 0.1 to 0.1 km per hour.

CALORIMETER

Records the number of calories you have burned.



HEART RATE MONITOR

Measures your heart rate in beats per minute.

BLOOD OXYGEN MONITOR

Measures oxygen levels in your blood.

SKIN TEMPERATURE

Records skin temp measurement.

Weekly Reminder: The skin temperature sensor will auto detect and adjust to your skin temperature. The skin temperature sensor will auto detect and adjust to your skin temperature. The skin temperature sensor will auto detect and adjust to your skin temperature. The skin temperature sensor will auto detect and adjust to your skin temperature.

19

SLEEP TRACKING

To use sleep tracking function, the device must be paired with the phone App. Make sure your device is sufficiently charged for the duration of the test. Sleep tracking is programmed to start automatically between 8PM to 8AM the next day (2000-0800). Make sure you are wearing the device on your wrist during the entire duration of the sleeping period. Adjust the strap for a snug yet comfortable fit. Do not forget to turn on Do Not Disturb function and/or lower the screen brightness. The data will be automatically uploaded to the phone App on the next day when you are using the App. The device can store up to 7 days of sleeping data without the phone.

FUNCTIONAL MODES

SPORT

Measures your performance during specific exercises. Long press to enter mode; short press to scroll through activities (Running, Treadmill, Cycling, Yoga, HIIT). Long press again to start or stop an activity.

MESSAGES

Shows incoming text messages from your smartphone. Long press to enter mode; short press to scroll through messages. Messaging alerts support Text, Messenger, Facebook, WhatsApp, Hangouts, Skype, Wechat, QQ and Line.

MORE

Access to settings and other modes. Long press to enter the menu; short press to scroll through functions.

20

DISPLAY VERSIONS

Enables Bluetooth version.

FIND

Helps you locate your smartphone. Long press to send a vibration alert to your smartphone.

BRIGHTNESS

Adjusts the display brightness. Long press to scroll through screen brightness levels.

Weekly Reminder: The screen brightness will auto detect and adjust to your environment. The screen brightness will auto detect and adjust to your environment. The screen brightness will auto detect and adjust to your environment. The screen brightness will auto detect and adjust to your environment.

SHUTDOWN

Long press to power down Koretrak Pro.

RESET

Resets Koretrak Pro's data and restores factory settings. Long press to reset.

STOPWATCH

Records time. Long press to start; short press to stop. Long press again to reset timer.

Weekly Reminder: The stopwatch function will auto detect and adjust to your environment. The stopwatch function will auto detect and adjust to your environment. The stopwatch function will auto detect and adjust to your environment. The stopwatch function will auto detect and adjust to your environment.

21

FEATURES VIA APP

- Koretrak Pro will vibrate when you receive a call or text message. To activate this function, you will need to set it up in the App under "Device".
- When you receive a call or text message, you will need to press the function button to decline the call.
- Message (i.e. Text, Messenger, Facebook, WhatsApp, Hangouts, Skype, Wechat, QQ and Line) alert needs to be turned on in "App" section.
- Alarm function can only be used on the App.
- Stand Up Reminder is adjustable from 10 to 180 minutes in increments of 5.
- You can link Koretrak Pro to Apple Health App.
- Find Device - This feature will allow you to locate your Koretrak Pro to yourself.
- Shake to Take a Photo - This will allow you to take a photo on your smartphone by shaking your wrist.
- Light Up - Koretrak Pro's screen will automatically turn on when your hand is raised.

22

- Distance Units - adjust by going to App, "Device" > "General".
- Display Timeout - adjustable by 5, 10, or 15 seconds.
- Heart Rate - you can set up a heart rate monitoring every hour.
- Do Not Disturb - select a time frame where you can turn off Koretrak Pro's vibrations, light or motion, or information push.
- 24-hour Time Setting - adjust by going to App, "Device" > "General".
- Safety Function - you will get a phone notification when you are away from your Koretrak Pro device. (This feature will not work if your Bluetooth is off.)

LANGUAGE SETTINGS:

You can change the language settings directly on the Koretrak Pro by selecting MORE/More and cycle through till you reach the language settings. To change the language settings through mobile app, go to "Device" > "General" while connected to your Koretrak Pro.

- English
- German
- French

SPECIFICATIONS:

Package Includes	Koretrak Pro, wrist band, instruction manual
Screen Size	1.08in
Bluetooth Version	4.0
Water Resistant Rating	IP67
Battery Type	Lithium Polymer
Battery Capacity	120mAh
Charge Time	1.5 - 2 hours
Input	5V - 60mA

23

Having difficulties setting up your watch?

We are here to help! Please visit <https://support.koretrahome.com> or scan the below QR codes for any urgent inquiries!



Support Contact

CE

The device complies with the European Directive 2014/53/EU. At the end of the service life, this product may be disposed of in the general household waste, but rather must be disposed of at a collection point for separating electrical and electronic devices. The materials are recyclable according to their labeling. We make an important contribution to protecting our environment by recycling, repairing, or reusing old devices in other ways. Please send the municipal administration where you live the device to be recycled in the nearest collection point. Subject to change.

Made in China, 2024.05.01, FCC ID: 3A96F-8885

FCC STATEMENT

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. **Caution:** The user is cautioned that changes or modifications not expressly approved by the manufacturer may void the user's authority to operate the equipment. This device has been tested and found to comply with the limits of a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Move the equipment away from electronic equipment. Consult the dealer or a qualified technician for help. This equipment complies with FCC's RF exposure guidelines for both for an uncontrolled environment. End user must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

UK FC